



### INSTALLATION INSTRUCTIONS

#### Required Tools:

- Universal Click & Click-R Type Plier Hose Clamp Collar Clips CV Boot Clamp (Optional)
- Flat Head Screw Driver
- Small Flashlight (Optional)

#### **Installation steps:**

1. Remove the OEM tension style clamps (Use pliers and/or other tool to compress clamp and release the locking mechanism)
2. Remove OEM sound chambers
3. Wipe the orifice where the sound chamber goes to remove old grease sediment (Use a clean cloth, you may also want to apply a thin layer of lubricant to facilitate the insertion of the CF chambers- this is optional and up to the user)
4. Place the provided Clamp(s) in the groove of the rubber air snorkel (same location where the old tension clamps were)
5. Insert the new CF chambers and line up correctly (using the incision on the rubber air snorkel, you will not miss it)
6. Tighten the clamp(s) using a regular flat head screw driver
7. End